

<b>Part Number</b>	<b>Description</b>	<b>Quantity</b>
1	Upper hopper	1
2	Adjusting screw	2
3	Upper shell	1
4	Lower shell	1
5	Dipstick	1
6	Checking screen	1
7	Output gate	1
8	Gear box	4
9	Base wheel	1
10	Current meter	1
11	Voltmeter	1
12	Electrical control box	1
13	Electrical control box support	1
14	Base	1
15	Motor	1
16	Pressing roller cover	1
17	Main shaft cap lock ring	1
18	Main shaft	1
19	Knife	1
20	Big bearing cap	1
21	Discharge plate	1
22	Main shaft big bearing	1
23	Main shaft small bearing	1
24	Connecting gear plate	1
25	Bevel gear	1
26	Pressing roller bearing	4
27	Pressing roller	2
28	Template	1
29	Horizontal shaft big bearing	1
30	Horizontal shaft cover	1
31	Angle gear	1
32	Horizontal shaft small bearing	1
33	Framework oil seal	1
34	Cushion	1
35	Gibbosity	1
36	Initiative shaft coupling	1
37	Passivity shaft coupling	1

